

PULSARS



Users Manual

PMV 5250


**DOUBLE OPTION
DC VENDING**

E-mail: info@pulsars.com
www.pulsars.com



PMV 5250 DC Vending

Double Selection


Front Side of the Control Key Board




Back Side of the Control Key Board



- Fill the water in main tank, it is unable to dispense.



- Wait few minutes to take drink.
- It is unable to dispense immediately.



- Ready mode.
- It is ready to dispense.

OPERATIONS

- To dispense coffee:

FULL CUP COFFEE
WELCOME 2 LIPTON

- Hot Water
- Full cup Coffee
- Half cup Coffee
- Full cup Tea
- Half cup Tea

Select
Your
Drink
'Full cup
Coffee'

HALF CUP COFFEE
WELCOME 2 LIPTON

- Hot Water
- Full cup Coffee
- Half cup Coffee
- Full cup Tea
- Half cup Tea

Select
Your
Drink
'Half
Cup
Coffee'.

- ◆ *Similar operations for dispense Tea.*

- To dispense hot water in Coffee side:

HAVE A HOT SIP
WELCOME 2 LIPTON

- Hot Water
- Full cup Coffee
- Half cup Coffee
- Full cup Tea
- Half cup Tea

Press
'Hot
Water'
key 1-2
seconds
till display
shows
'Flushing
C/T'.



FLUSHING C/T
WELCOME 2 LIPTON

- Hot Water
- Full cup Coffee
- Half cup Coffee
- Full cup Tea
- Half cup Tea

Press
'Coffee'
to
take hot
water in
Coffee
side

- ◆ *Similarly for dispensing of hot water in Tea side.*


- To display the 'Counts' and 'Temperature':




◆ *Similarly for Tea.*

Tips: When you finished your counts, the display automatically returns to dispense mode in 10 seconds.


▪ To display the Temperature.



Go to 'counts mode' and press 'Hot water' key again.




Then press 'Full cup Coffee' key.




It shows the current temperature.

▪ To manually fill the Boiler:






Continually press 'Hot water' key, till boiler is filled.



When you release the key, the manual refilling is stopped.

▪ Programming the Control Card:



Tips: These four keys function differently in this mode.

Press menu key once.

- Factory set of Password value = 0
- Use Up / Down arrow key to bring your password on the screen.
- Then press Store key to enter the 'Settings mode'.

HOW TO SET ALL PROGRAMS?


- First go to the settings mode.

Tips:

Powder time should be < water time by atleast 1 second.


A) Coffee Water.

B) Coffee Powder.



Water Set for Coffee:

It shows 'Coff Wat' on display, then set the value by using Up / Down arrow keys. And press 'store' key to accept.



Powder Set for Coffee:

It shows 'Coff Pow' on display, then set the value by using Up / Down arrow keys. And press 'store' key to accept.

◆ *Similarly for other drinks*

C) Tea Bag Mode.

TEA BAG MODE: N
WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	↑	Full cup Coffee
<input type="checkbox"/>	○	↓	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Tea Bag mode:

It shows 'Tea Bag mode Y/N: N' on display, then set the value by using 'Demo' key. And press 'store' key to accept.

D) Temperature set.

SET TEMP – 82
WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	↑	Full cup Coffee
<input type="checkbox"/>	○	↓	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Temp. Set:

It shows 'SET TEMP' on display, then set the value by using Up / Down arrow keys. And press 'store' key to accept.
Min: 72
Max: 95

E) Coin mech. Set.

COIN MECH Y/N: N
WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	↑	Full cup Coffee
<input type="checkbox"/>	○	↓	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Coin mech:

It shows 'Coin mech Y/N: N' on display, then set the value by using 'Demo' key. And press 'store' key to accept.

F) Initial boiler fill.

INT.B.FIL Y/N: N
WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	↑	Full cup Coffee
<input type="checkbox"/>	○	↓	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Initial boiler fill:

It shows 'INT.B.FIL Y/N: N' on display, then set the value by using 'Demo' key. And press 'store' key to accept.

G) Auto clean.

Auto Clean Y/N: N
 WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	▲	Full cup Coffee
<input type="checkbox"/>	○	▼	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Auto clean:

It shows 'Auto clean Y/N: N' on display, then set the value by using 'Demo' key. And press 'store' key to accept.

H) Half cup enabled.

HALF CUP ENABLE-Y
 WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	▲	Full cup Coffee
<input type="checkbox"/>	○	▼	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Half cup enable:

It shows 'Half cup enable Y/N: N' on display, then set the value by using 'Demo' key. And press 'store' key to accept.

I) Change Password.

COIN MECH Y/N: N
 WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	▲	Full cup Coffee
<input type="checkbox"/>	○	▼	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Password Set:

It shows 'Change Password' on display, then set the value by using Up / Down arrow keys. And press 'store' key to accept.

**Min: 0
Max: 9999**

J) Exit from the program.

EXIT
 WELCOME 2 LIPTON

<input type="checkbox"/>	○		Hot Water
<input type="checkbox"/>	○	▲	Full cup Coffee
<input type="checkbox"/>	○	▼	Half cup Coffee
<input type="checkbox"/>	○	D	Full cup Tea
<input type="checkbox"/>	○	S	Half cup Tea

Ending program